Chroma-Q™ Plus™

User Manual





Version 1.1 January 2006

PN: 103-0078

Disclaimer

The information contained herein is offered in good faith and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information should not be used in substitution for customer's tests to ensure that Chroma-Q products are safe, effective, and fully satisfactory for the intended end use. Suggestions of use shall not be taken as inducements to infringe any patent. Chroma-Q sole warranty is that the product will meet the sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted.

Chroma-Q reserves the right to change or make alteration to devices and their functionality without notice due to our on going research and development.

The Chroma-Q Plus has been designed specifically for the professional entertainment lighting industry. Regular maintenance should be performed to ensure that the products perform well in the entertainment environment.

If you experience any difficulties with any Chroma-Q products please contact your selling dealer. If your selling dealer is unable to help please contact support@chroma-q.com. If the selling dealer is unable to satisfy your servicing needs, please contact the following, for full factory service:

Outside North America: North America:

Tel: +44 (0)1494 446000 Tel: 416-255-9494 Fax: +44 (0)1494 461024 Fax: 416-255-3514

support@chroma-q.com support@chroma-q.com

For further information please visit the Chroma-Q website at www.chroma-q.com.

Chroma-Q is a trademark, for more information on this visit www.chroma-q.com/trademarks.

The rights and ownership of all trademarks are recognised.

Table of Contents

1.	Prod	duct Overview	3
2.	Ope	ration	4
	2.1	Control and power cables	4
	2.2	Gel loading and replacing	5
	2.3	Operating the unit	7
	2.4	Mounting the unit	
	2.5	Safety wire	
	2.6	Troubleshooting	12
	2.7	Technical overview	13
	2.8	Technical specifications	14
3.	Mair	ntenance and storage	15
4.	Drav	wings	16
	4.1	Outside dimensions	16
	4.2	Gel string schematic	17
	4.3	Mounting bracket positions	18

1. Product overview

The Chroma-Q Plus takes colour changer technology to a new level. The Chroma-Q Plus is designed to give years of trouble free use, providing that it is regularly maintained and is used in accordance with the instructions detailed in this manual. The Chroma-Q Plus is fully compatible with the Chroma-Q Original.


Note: This manual describes functionality available from version 1.0 of the Chroma-Q Plus software. For the latest software updates, documentation, and other information about all Chroma-Q products, please visit the Chroma-Q website at www.chroma-q.com.

The Chroma-Q Plus is designed to operate on the ANSI E1.11 USITT DMX 512-A protocol. This multiplexed serial data system allows for the individual addressing of multiple units on one data cabling system. The unit utilises one or two DMX channels depending on the mode of operation.

The unit is addressed by using the three embossed push button switches and LED display found on the user interface panel located on the bottom of the body. These switches are also used to select cooling fan speed, 'gel saving' mode, scrolling speed, display lighting, remote operation, and reset.

Another feature of the user interface panel is a diagnostic section on the LED display showing Power, DMX signal and signal strength.

- The first vertical bar indicates that there is Power (24V DC) at the unit.
- The second vertical bar indicates that there is Data (DMX) at the unit.
- The horizontal bars indicate the data Signal Level (DMX) at the unit.
 - 1^{st} bar = 25-49%
 - 2^{nd} bar = 50-74%
 - -3^{rd} bar = 75-100%



User Interface Panel

The Chroma-Q Plus is supplied power and control signals by means of two 4-pin XLR style connectors on the rear panel, allowing multiple units to be 'daisy-chained' into the same line of cabling. Patching the output from the last unit back into the power supply will terminate the DMX for each chain line and ensure even power voltage across all colour changers in that chain.

Note: The quantity of Chroma-Q Plus colour changers, and maximum cable length per power supply output is dependant upon the size of PSU / Splitter box used. (See later in this manual for details.)

The rear of the unit is designed to accept four point mounting brackets for fixture colour frame sizes 158mm/6½" to 254mm/10". An option with this unit is the innovative Universal Mounting Bracket which is one bracket that can be adjusted to fixture sizes 158mm/6½" to 254mm/10".

Chroma-Q Plus safety information

Warning: This product is for professional use only. It is not for household use.

Read this manual before powering or installing the colour changer, follow the safety precautions listed below and observe all warnings in this manual and printed on the accessory.

If you have question about how to operate the colour changer safely, please contact your Chroma-Q dealer or e-mail support@chroma-q.com.

Protection from electric shock

- Do not expose the colour changer to rain or moisture
- Refer and service operation not described in this manual to a qualified technician

Protection from burns and fire

- Keep flammable materials well away from the colour changer
- Provide a minimum clearance of 0.1m (4 inches) around air vents
- Do not modify fixture accessory or install other than genuine Chroma-Q parts

Protection from injury due to falls

- When mounting the colour changer, verify that the fixture frame can hold the weight of the device
- Verify that all external covers and rigging hardware are securely fastened and use the supplied means of secondary attachment, the safety cable.
- Block access below the work area whenever installing or removing the colour changer.

2. Operation


- 2.1 Control and power cables
- 2.2 Gel loading and replacing
- 2.3 Operating the unit
- 2.4 Mounting the unit
- 2.5 Safety wire
- 2.6 Troubleshooting
- 2.7 Technical overview
- 2.8 Technical specifications

2.1 Control and power cables

The Chroma-Q Plus utilises an XLR 4-pin cable system. This is used for power and data transfer. Pins 2 and 3 are for ANSI E1.11 USITT DMX 512-A data. Pins 1(-) and 4(+) are for 24VDC power.

Damage will occur if power connections short to data or ground/shield connections. When assembling XLR 4-pin cables, heat shrink should be used on each individual pin to prevent short circuits (Tourflex Ultra Datasafe P&D cable recommended). See diagram below.

Note: It is very important to ensure that the drain wire from the cable shield is connected to both XLR connector cases.



Detail of connector wiring (typical)


Pin #	Pin #	Minimum Cable size
1	Ground (-ve)	2.50mm ² (14 AWG)
2	Control data minus (-)	0.35mm ² (22 AWG)
3	Control data plus (+)	0.35mm ² (22 AWG)
4	24V DC (+ve)	2.50mm ² (14 AWG)
Chassis	Cable shield/drain wire	0.25mm ² (24 AWG)

Note: Cable length should not exceed 60m/200ft with return line

Connections

Correct cabling procedure and connection of the units to the power supply will increase signal strength and prevent malfunction. Please follow these basic rules.

- a) Use the correct type and gauge of cable and connectors. (Tourflex Ultra Datasafe P&D cable recommended).
- b) Keep cable runs as short as possible to reduce line loss.
- c) It is recommended to use a return cable for each run. This will ensure balanced DC power to all units, where the line is correctly terminated, and all units receive power if one link of the chain is faulty.



Total cable length should not exceed 60m/200ft with return line

Note: Standard signal input is a male XLR chassis connector and output is a female XLR chassis connector.

Warning: Always ensure that safety wire is connected before final inspection.

2.2 Gel loading and replacing

Introduction

Changing the gel strings is easy, but it may take some time and practice to accomplish, if the user is not familiar with these types of colour changers.

There are two methods of loading gel strings on the Chroma-Q Plus, manually or using the power assisted loading method ('PAL Load').

Note: It is suggested that new users of this product load the gel strings by the manual method until they become familiar with the units.

Gel description

The standard gel string consists of a head, gel frames and a tail. Pro Color HT+, Rosco Supergel and GAMcolor are the recommended media. The head and tail are taped to metal gel tabs which are then attached to the plastic hooks on the centre of the Take-up Reels (TUR).

Gel string dimensions and assembly

To join a leader, tail and gel together, a high temperature, clear gel tape is recommended.

To join leader and tail to reels, metal gel tabs are required.



Position the gel tab at the end of the gel string. Tape the gel tab to the gel string both vertically and horizontally




Fold back the gel tab and cut out a notch from the gel string



Click the gel tab on the hook of the take up reel

The completed string should look like this:




Note: A range of completed custom gel strings are available upon request. Contact the selling dealer for details. When ordering gel strings please state the Chroma-Q model the gel string will be built for.

Warning: Because of the gel saver mode the Chroma-Q Plus the gel strings have a longer frame. A GL gel string should be used to maximise the effect of this mode. An original gel string will fit and operate also, but the performance will be compromised.

Manual Loading

- 1. Remove Take-up Reel (TUR) by opening lid and pulling out both TUR.
- 2. Make hole in gel string at V-notch on tail end and hook tail end of gel string to the black fixed TUR.
- 3. Wind the gel string onto the black TUR.
- 4. Hook head end of gel string to the gray Spring Loaded TUR.
- 5. Insert both TUR on color changer shafts and DO NOT engage them to the hubs.
- 6. Hold **black** TUR and turn **grey** TUR 3 full turns to engage spring tension.
- 7. Press both TUR down, locking them onto the hub with out releasing the spring tension. The TURs may need to be rotated a little to locate the hub pins.
- 8. Plug in the colour changer, and check that it goes through the initialisation sequence correctly. Check that the gel runs smoothly and does not bind up on the TUR's.
- 9. Run a test sequence to allow the gel string to 'bed' in. The unit does not have to be attached to a lighting fixture to perform this operation. It is recommended that this sequence is run for a few minutes (or 3 to 4 times, end-to-end).



Important Notes:

- For normal operation, the start of the gel string is on the left-side TUR and the end of the string on the right-side TUR, when viewed from the front of the unit.
- Do not power lights without powering up the colour changer first. The fan must be running in order to protect gels from premature failure.
- High fan speed is recommended on all lighting fixtures of 750 Watts and above.
- Poorly optimised light bulbs in some fixtures may result in premature gel failure.

Power Assisted Loading ('PAL-Load')


See also: 'Operating the unit' and drawing sections of this manual.

'PAL-Load' controls the direction of the Take-up Reels (TUR) with the UP and DOWN button. In this mode the user can wind and unwind the gel string using the color changer motor. With practice this will allow for speedier loading and unload of gel strings.

- Open lid and remove Take-Up Rollers (TUR) and old gel string if necessary.
- 2. Hook tail end of gel string to the **black** Fixed TUR.
- 3. Insert and lock **black** TUR and gel string into color changer. The TUR may need to be rotated a little to locate the hub pins.
- 4. Apply power to the unit while holding down the MENU button. The display will show the legend PAL.
- 5. Press and hold *DOWN* until gel string is wound onto black TUR.
- 6. Insert grey TUR on color changer shafts and DO NOT engage it to the hub.
- 7. Hold **black** TUR and turn **gray** TUR 3 full turns to engage spring tension.
- 8. Press **grey** TUR down, locking it into the hub with out releasing the spring tension. The TUR may need to be rotated a little to locate the hub pins.
- 9. Allow the unit to self-calibrate by pressing the *UP* and *DOWN* buttons simultaneously, or by unplugging and re-plugging the colour changer.
- 10. Run a test sequence to allow the gel string to 'bed' in. The unit does not have to be attached to a lighting fixture to perform this operation. It is recommended that this sequence is run for a few minutes (or 3 to 4 times, end-to-end).

2.3 Operating the unit

All the unit functions are accessed using the LED display and the three push-button switches on the bottom panel.



Control	Function
MENU Button	Mode access, record and escape
UP Button	Decrements (-) the mode level or value
DOWN Button	Increments (+) the mode level or value
3 digit display	Displays mode, monitor or blank display

Control description

The MENU button is used to scroll through the different modes of operation, and the UP or DOWN buttons used to select the level, or value, in that mode.

If any mode or value is changed the display will begin flashing;

- To restore the previous value, press and release the MENU
- To record the change depress and hold the MENU button for 2 seconds or until last character stops flashing

Display operation

Power-up display

On power-up, the unit will go through its self-calibration mode and the display will show the units software version. (i.e. 1.0.0)




After the self-calibration finishes, the display will show the DMX address mode. (i.e. 0.0.1)



Monitor Display

If left undisturbed for 5-7 seconds, the display will revert to 'Monitor Mode'



- The first vertical bar indicates that there is Power (24V DC) at the unit.
- The second vertical bar indicates that there is good Data (DMX) at the unit.
- The horizontal bars indicate the data Signal Level (DMX) at the unit.
 - 1st bar = 25-49%
 - 2^{nd} bar = 50-74%
 - 3^{rd} bar = 75-100%

See also: 'Troubleshooting' section of this manual.

Display Flip

The display-viewing angle can be flipped through 180° by pressing the MENU and DOWN button simultaneously.

Display Mode

The display can be set to auto-blackout after 12 seconds. This is selected through the mode menu under 'dP', where dP0 is OFF and dP1 is ON.

Reset

If the MENU and the UP button are pressed and held for 1 second, the unit will reset to the factory default settings. This feature is particularly useful when the units are used in many different configurations or shows.



The reset function is also available through 'Remote Operation'

Modes of operation Important Notes:

- The MENU button is used to scroll through the different modes of operation, and the UP or DOWN buttons used to select the level or value, in that mode.
- If any mode or value is changed, the display will flash until the MENU button is pushed and held for 2 seconds to record the change.
- When the MENU button is held for 2 seconds, the unit will save the change(s) and these 'user defaults' will take precedence immediately.
- If MENU button is not held for 2 seconds to previous value will be displayed
- The unit will not save any change(s) made by remote control after the next power cycle.

DMX addressing mode

This mode is used to set DMX data address of the unit. The unit uses one or two DMX channels depending which mode it is operating.

The display shows the current DMX address (between 1 and 512).

To alter the address, press UP or DOWN button once to increment or decrement the value; hold down the UP or DOWN for fast increments and decrements of the value.

See also: 'Remote Operation' later in this section.

Fan speed mode (Fn)

This mode is used to set the gel cooling-fan speed of the unit. This feature can be used in environments where a lower noise level is required, although this may decrease gel string life. The display shows the current gel cooling fan speed. There are four fan speeds, 1 is the slowest and 4 is the fastest.

Press UP or DOWN once to increment or decrement the value.

See also: 'Remote Operation' later in this section.

Gel saver mode (GL)

Gel-saver mode is used to switch the gel-saving mode on or off. This feature slowly moves the chosen gel frame back and forward slightly so that the heat build-up is dissipated over a larger area, extending the life of the gel string. Press the UP or DOWN buttons once to switch between On (1) and Off (0) (the default is Off). Press hold MENU for 2 seconds to save the new setting. This feature is also available via DMX (see "Remote operation" section of this manual).

A Chroma-Q Plus gel string should be installed to maximise the effect of this mode.

Speed mode (SP)

This mode is used to set the scrolling speed of the unit. This feature allows the gel string to move at a higher speed, for more rapid changes. Use of this high speed will generate more noise from the unit. Press the UP or DOWN buttons once to switch between Standard (1) and Fast (2) (the default is Standard). Press and hold MENU for 2 seconds to save the new setting. This feature is also available via DMX (see "Remote operation" section of this manual).

Display mode (dP)

This mode is a two step feature set with the UP and DOWN button, on (1) and off (0). Default is off (0). When set to dP1 the display will change to diagnostic mode after 6 seconds. When set to dP0 the display will change to the diagnostic mode in 6 seconds, then clear in another 6 seconds, making 12 seconds till auto-blackout. The display will return to diagnostic mode with the first button press and will do the action of the second press.

Remote Operation mode (ro)

This mode is used to switch between the different remote operation modes in the unit. The use of these different modes greatly enhances the versatility of the unit by giving the user remote control of some functions.

There are three remote operation modes:

Mode 1 = Single-channel DMX operation. The channel controls the colour selection Mode 2 = Dual-channel DMX operation. The 1 st channel controls the colour selection. The 2 nd channel controls the fan speed;	Mode 2 = C				
selection. The 2 nd channel controls the fan speed;		Mode 2 = Dual-channel DM	V aparation. The 1st channel controls the colour		
· ,	s		Dual-channel DMX operation. The 1st channel controls the colour		
		selection. The 2 nd channel controls the fan speed;			
0-24% = Fn 4(fast), 25-49% = Fn3, 50-74% = Fn2, 75-100% = Fn1 (slower field)	0-24% = Fn 4(fast), 25-49% = Fn3, 50-74% = Fn2, 75-100% = Fn1 (s				
Mode 3 = Dual-channel DMX operation. The 1 st channel controls the colour	Mode 3 = C	Mode 3 = Dual-channel DM	X operation. The 1 st channel controls the colour		
selection. The 2 nd channel controls the units other functions.	S	selection. The 2 nd	channel controls the units other functions.		
These functions Ch. 2 Level Feature	unctions	functions Ch. 2 Level	Feature		
initialise two 0-5% = No feature	e two	se two 0-5%	= No feature		
seconds <u>after</u> 6-15% = Fan off	s <u>after</u>	ds <u>after</u> 6-15%	= Fan off		
the channel level 16-25% = Fan speed 1 (slowest)	nnel level	annel level 16-25%	= Fan speed 1 (slowest)		
is entered. 26-35% = Fan speed 2	ed.	ered. 26-35%	= Fan speed 2		
36-45% = Fan speed 3		36-45%	= Fan speed 3		
46-55% = Fan speed 4 (fastest)		46-55%	= Fan speed 4 (fastest)		
56-65% = Gel Saver off		56-65%	= Gel Saver off		
66-75% = Gel Saver on		66-75%	= Gel Saver on		
76-85% = Motor speed normal, see Speed mode (SP)		76-85%	= Motor speed normal, see Speed mode (SP)		
86-95% = Motor speed fast, see Speed mode (SP)		86-95%	= Motor speed fast, see Speed mode (SP)		
96-99% = Reset (reset to user defaults)		96-99%	= Reset (reset to user defaults)		

The display shows the current Remote Operation mode of the unit. Press UP or DOWN to increment or decrement the mode setting.

Default Settings

'Factory' default settings

If the MENU and the UP button are pressed and held for 1 second, the unit will reset to the factory default settings. This feature is particularly useful when the units are used in many different configurations or shows.



The reset function is also available through 'Remote Operation' The 'Factory' default settings put the unit in the manufacturer operating mode.

Fan Speed =4 (fast)
Gel Saver =0 (Off)
Gel Speed =1 (slow)
Display =1 (On)
Rmt.1 (normal)
Operation = standard
Display Flip =

'User' default settings

Each time the MENU button is pressed and held for 2 seconds, the unit will save that change and these 'user defaults' will take precedence immediately.

These 'User' defaults can be reset to the 'factory' defaults using the method detailed above.

Summary of control functions

Operation or	Description	Actions required	Display
Mode			
Power-Up	Software version shown on the unit(s) at power-up.	This shows the software version while the unit is self-calibrating, before displaying the 'Monitor Mode'.	
reSet	This will reset the unit to the default settings.	While holding down MENU and DOWN button for 1 second.	E.E.E.
Power Assisted Loading ('PAL-Load')	Used to load a gelstring into the unit.	Hold down the MENU button during power- up. Pressing the UP button will advance the fixed TUR. Pressing the DOWN button will advance the spring TUR. Press both DOWN & UP buttons, or cycle the power, to re- calibrate.	B.B.B.
See also, gel loading instructions			

Modes (Use the MENU button to scroll through these modes)

wodes (Ose the MENO batton to scioli through these modes)				
DMX addressing Mode	Used to set the units DMX data address	The display shows DMX address (1-512). Press DOWN or UP <u>once</u> to increment or decrement the value, <u>hold down</u> the DOWN or UP for fast increment or decrement.		
See also, DN	IX addressing instructi	ions		
Fan speed Mode	Used to set the fan speed of the unit.	The display shows the current gel cooling fan speed. There are four fan speeds, 1 is the slowest and 4 is the fastest. Press UP or DOWN once to increment or decrement the value,		
See also, fan speed instructions				


' G el Saver' Mode	Switches on/off the gel saving mode.	The display shows the current gel saver mode. Press UP or DOWN <u>once</u> to switch between on (1) and off (0).	
	saver mode instruction	ns	
' sp eed' Mode	unit.	The display shows the current gel scrolling speed. There are two scrolling speeds. 1 is the slowest, 2 is the fastest. Press UP or DOWN once to increment or decrement the value,	B.B.B.
	scroll speed instructio		
' d is P lay' Mode	Switches on/off the display	Switches the display on or off. Display will re-activate when any button is pressed. Press UP or DOWN to switch between on(1) and off(0).	
See also, dis	play mode instructions		
'remote- operation'	Mode1 = single DMX channel operation. Mode 2 = Dual DMX channel operation (Colour/Fan speed) Mode 3 = Dual DMX channel operation (Colour/Function)	The display shows the current DMX mode of the unit. There are three DMX modes Press UP or DOWN button to increment or decrement the mode setting,	


2.4 Mounting the unit


The Chroma-Q Plus is designed to mount in a variety positions <u>but</u> with the base of the unit below the fixture. Do not mount in an inverted position with the base of the unit above the fixture, as the rising heat from the fixture may cause the gel string damage.

The rear of the unit has four re-enforced mounting stands with an M4 sleeved thread inserted. The spacing of these stands are set to accommodate standard mounting brackets for fixture colour frame sizes of $158 \text{mm}/6\frac{1}{4}$ ", $190 \text{mm}/7\frac{1}{2}$ ", $215 \text{mm}/8\frac{1}{2}$ ", and 254 mm/10".

Also available is the Universal Mounting Bracket shown below. This is one bracket that can be adjusted to fixture sizes from 158mm/61/4" to 254mm/10", Chroma-Q part number 110-0109.







This Universal Bracket has two pairs of threaded holes for each leaf, and each leaf has two slots and two alignment holes. Four frame sizes are achievable;

- To set the frame size to 158mm (6 1/4") use the inner threaded holes on the bracket and align the outer hole on the leaf with the inner hole on the bracket.
- To set the frame size to 190mm (7 ½") use the outer threaded holes to secure the leaf and align the outer hole on the leaf with the outer hole on the bracket.
- To set the frame size to 254mm (10") remove the leafs.

The leaves and bracket have holes which align to 158mm (6½"), 190mm (7½"), and 215mm (8½"). The leaves can be removed to give a 254mm (10") mounting frame.


See section 5 for all possible frame connections

2.5 Safety wire

The Chroma-Q Plus should always be used with the safety wire provided.

2.6 Troubleshooting

The LED display aids in the troubleshooting of the **Chroma-Q Plus** system. These indicators are located on the bottom of each unit.



- The first vertical bar indicates that there is Power (24V DC) at the unit.
- The second vertical bar indicates that there is Data (DMX) at the unit.
- The horizontal bars indicate the data Signal Level (DMX) at the unit.
 - 1^{st} bar = 25-49%
 - 2^{nd} bar = 50-74%
 - 3^{rd} bar = 75-100%

Note: The signal level changes during normal operation of the unit.

Symptom	Possible Cause	Solution
Unit does not respond to	Unit set to wrong DMX	Check DMX address settings.
DMX control, but DMX	address.	
display indicator is on.		
Unit does not respond to	Bad Cable.	Check cable and DMX run
DMX, DMX display indicator	No DMX at Splitter/ PSU.	from console.
is off.		
Units run at different speeds.	Colour changer speed	Check all colour changer
	settings may be different.	speed settings.
	Cable lengths are too long.	Check the cable length and
	No cable return line.	configuration.
		Ensure there is a cable return
		line in the system.
Chroma-Q Plus units have dim	Cable runs too long.	Check voltage levels on last
display indicators and run	Too many units on one chain	unit. Should not be below
slowly.	overloading PSU.	20VDC.
DMX display indicator is off	Colour changer not	Check cable
on one unit.	connected.	
	Bad cable.	
	Damaged transceiver IC in the	Send unit back for repair.
	colour changer.	

Display Indicators appear OK	Mechanical (or electrical)	Turn unit on and off.
but gel string does not move.	failure in the unit.	Return unit for repair.
Gel burns too quickly.	Fans have failed or are too	Check fans are operating.
	slow.	
	Poorly optimised lamp focus	Optimise bulb focus.
	in fixture.	
	IR filter medium not fitted.	Replace gel strings and install
		IR filter.

Note: A high percentage of problems are a direct result of poor cable and corrupt DMX control signals.

2.7 Technical overview

The colour transport system employs an opto-electronic system for accurate positioning of the gel string. When the unit initially receives power it will go through a calibration sequence. The purpose of the initial calibration sequence during power up is to determine the total length of the gel string and therefore the position of the different gels.

Note: Over time the gel string may warp slightly. This may alter the positions of the gels relative to their pre-programmed DMX values and therefore some 'fine-tuning' may be required.

The motor has an optical encoder feedback system. The purpose of this is to convert motor revolutions in to electronic pulses, and also to determine which direction the motor is turning.

The electronic cards consist of three key components: L6225 motor driver, 75176 transceiver and a processor. The L6225 is a true digital device receiving two PWM signals to operate speed and direction. The 75176 transceiver operates in the receive configuration to convert serial protocol to a TTL level. All data relevant to the operation of the unit is stored onboard in 'flash' memory.

The majority of electronics problems are usually created by external factors such as shorted cables, etc. The 75176 transceivers are susceptible to damage if 24VDC is present on the DMX signal lines.

Routine maintenance can prevent most mechanically based problems. The motor mounting plate can be adjusted to control tension on the belt. Excessive belt tension is often the cause of noise and poor performance. Conversely, loose motor belts can cause accuracy problems.

Troubleshooting is a process of elimination. First, rule out the other field factors (i.e. faulty cables, power sources). If an electronics problem is suspected inside the unit replace the electronics card first. If accuracy problems should occur and mechanical problems have been ruled out, replace optical sensors. For technical advice and or parts, please contact your selling dealer or the offices listed in this manual.

2.8 Technical specifications

Dimensions: 286mm (w) X 297mm(h) X 92mm(d)

11.25" (w) X 11.69" (h) X 3.61" (d)

Weight: 2.04kg / 4.5 lb (without mounting frame)

Aperture: 171mm / 6.75"

Colour media: Pro Color HT+, Rosco and GAMcolor recommended

Gel capacity: 2-20 frames

Cooling: Forced air

Cooling speed: 4 speeds

Addressing: Digitally, via push buttons (3) and LED display

Working Voltage: 24 VDC (+/- 10%)

Power consumption: 1 Power Unit (PU) (see note below)

DMX protocol: ANSI E1.11 USITT DMX 512-A

Body material: UL94 V0 rated reinforced PBT compound

Body color: Black (white option)

Mounting plate: Optional fixed or universal mounting system fits 160-254mm/

61/4"-10" fixtures

Connectors: XLR-4 (male) in and XLR-4 (female) through

European approvals: Complies with EU directives: EMC89/336/EECClass A.

Harmonised standards applied in order to verify compliance with

directives: EN 56022:1994, EN50082-1: 1992 & EN 60950

North American approvals: Radiated Emissions: Complies with FCC part 15 subpart B, class

A for unintentional radiators. Low Voltage Directive: Complies

with CSA 22.2 950, UL 1950

Note: We use the Power Unit (PU) to simplify the load calculation on any given Chroma-Q power supply. For example a PSU12 will supply up to 12 PU. So you can plug-in 12 Chroma-Q Plus, 8 Chroma-Q Universal, or a combination of 8 Chroma-Q Plus and 4 Chroma-Q Universal on one PSU08.

3. Maintenance and storage


The Chroma-Q Plus should be stored in a dry and cool environment, safely secured to prevent from falling on a hard surface.

The unit may be exposed to dirty environments containing many air particles. This can lead to dust and dirt build-up in the vents and fan area. The unit should be vacuumed to remove dust and dirt. This can be done with a painters brush and vacuum. Simply brush the dust out of the vents and fan into a vacuum cleaner. DO NOT use compressed air to blow dust and dirt into the unit.


If there is any oily residue on the body of the unit or the gel string wipe off with a damp cloth ensuring that no water enters the fan or vent area affecting the electronics.

The gel string should be inspected for wrinkling and cracking. If there are signs of wear a new gel sting should be installed.

4. Drawings4.1 Outside dimensions of the unit



4.2 Gel string schematic



4.3 Mounting bracket positions

